



Firmware update instructions

To update the firmware of the Blueway device, please follow the steps below:

- Copy the proper update file from the update package and copy to the root of the USB flash drive.
- Then connect the USB drive to the Blueway while it is powered up.
- If there is an iPod connected to the Blueway you can leave as it is, in any playback mode or status, you do not need to disconnect or stop playback.
- Update procedure will start automatically within a few seconds and takes approximately 1 minute.
- Do not disconnect the USB drive within this time.
- During the update the head unit (car stereo) turns to tuner mode and the Blueway restarts.
- When finished, change source to CD-Changer to use the Blueway again.
- After a successful update the update file is deleted from the USB flash drive and you can see the new firmware version in the Settings/About menu.