

Follow the steps below to update firmware:

Extract the **G3AB_UPD.ROM** file from the update package and copy to the root of an USB flash drive, then connect the USB drive to the Gateway 300 V2 while it is powered. If there is an iPod connected to Gateway you can leave as it is in any playback mode or status, do not need to disconnect or stop playback.

Update procedure will start automatically within few seconds and takes cca. 1 minute. During the update head unit (car stereo) turns to tuner mode and Gateway restarts.

When finished, change source to CD Changer to use it again. No other configuration is necessary, previous settings are kept.

After a successful update G3AB_UPD.ROM is deleted from the USB drive.

For more information read [Knowledge Base](#) or contact Dension Support at support@dension.com

Please note:

This update was created only for the Gateway 300 v2. Please do not use it if you have Gateway 300 v1.

Avoid unnecessary updates. If your system works fine as expected, please do not update!