

Before connecting the Gateway Lite MOST (GWL) device to the MOST ring it requires a car configuration procedure. The default car setting of the GWL is Mercedes. Depending on the car type it requires a different car configuration file.

Car configuration procedure of the Gateway Lite MOST:

1. Copy the appropriate GW_CFG.BIN file to the root of a USB flash drive
2. Connect the flash drive to the GWL MOST when it is not powered
3. Please connect the power cable to the GWL MOST
4. The GWL will start booting. In the meantime the configuration procedure will start automatically. Wait about 1 minute.
5. Connect the GWL to the MOST ring
6. Turn the ignition & Head Unit ON and test the GWL functionalities
7. Finish the installation of the Gateway Lite MOST