

Follow the steps below to update firmware:

Extract the G3AH_UPD.ROM file from the update package and copy to the root of a USB flash drive. If possible please also **copy 2-3 MP3 files** to the USB device, again to the root, then connect the USB drive to the Gateway Lite while it is powered up.

If there is an iPod connected to the Gateway Lite you can leave as it is, in any playback mode or status, you do not need to disconnect or stop playback.

Update procedure will start automatically within a few seconds and takes approximately 1 minute. **Do not disconnect the USB drive within this time.** During the update the head unit (car stereo) turns to tuner mode and the Gateway restarts.

When finished, change source to CD-Changer to use the Gateway Lite again.

After a successful update G3AH_UPD.ROM is deleted from the USB flash drive and GW_EES.BIN file will appear with the new software version.

For more information read [Knowledge Base](#) or contact [Dension Support](#).